



DESKNEKO CARE

Laptop Sleeve Care Guide



Gentle care for laptop sleeves, soft tech bags, and everyday carry pouches.



Spot clean first

Soft cloth, cold to lukewarm water, mild soap only if needed.



Hand wash when needed

Use gentle pressure. Do not twist, wring, or scrub hard.



Machine wash only if needed

Never use bleach or a dryer. Air dry fully before use.

1 Upon receiving



- Empty packaging and check seams, zipper areas, and edges.
- A light new-product smell can be normal and should fade after airing out.
- Contact us if you notice a defect.

2 Daily care



- Remove dust with a soft dry cloth.
- Blot spills quickly before stains settle.
- Avoid overstuffing, sharp objects, ink, oils, and abrasive surfaces.

3 Spot clean RECOMMENDED



- Use cold to lukewarm water and a soft cloth or sponge.
- Add a tiny amount of mild soap only when needed.
- Clean the outside gently. Do not soak seams, zippers, or padded areas.

4 Hand wash WHEN NEEDED



- Use low-temperature water and mild soap.
- Press gently instead of twisting, wringing, or hard scrubbing.
- Rinse lightly and press moisture out with a towel.

5 Machine wash ONLY IF NECESSARY



- Use a mesh bag or pillowcase to reduce friction.
- Choose low temperature, delicate settings, and mild soap.
- Do not use bleach or wash with rough/heavy items.
- Remove promptly and reshape gently.

6 Air dry only



- Turn inside out when possible, then hang in a clean ventilated place.
- Never use a dryer, iron, heater, or direct hot airflow.
- Let it dry fully before using or storing.



Avoid bleach



No dryer



No harsh solvents



No hard scrubbing



Avoid sharp objects

www.deskneko.com/care

Gentle care first. Use the product page or care label for item-specific instructions.