



DESKNEKO CARE

RGB-LED Desk Mat Care Guide



Safer cleaning for RGB-LED desk mats with USB, controller, and light-edge parts.



Spot clean first

Soft cloth, cold to lukewarm water, mild soap only if needed.



Hand wash when needed

Use gentle pressure. Do not twist, wring, or scrub hard.



Never machine wash

Never use bleach or a dryer. Air dry fully before use.

1 Unplug first



- Disconnect power before any cleaning.
- Keep the USB plug, controller, cable, and LED edge dry.
- Do not reconnect until everything is fully dry.

2 Daily care



- Wipe dust with a soft dry cloth.
- Blot spills immediately and keep liquid away from electronics.
- Avoid pulling, bending, or crushing the cable area.

3 Spot clean only RECOMMENDED



- Use a barely damp cloth or sponge on the surface only.
- Use mild soap sparingly, then remove residue with a clean damp cloth.
- Never soak or submerge any part of the mat.

4 Keep electronics dry



- Do not let water reach the controller, USB plug, cable, or LED edge.
- Do not spray cleaner directly on the mat.
- Avoid harsh solvents, bleach, alcohol-heavy cleaners, and acidic cleaners.

5 No machine wash RGB MATS



- Never machine wash, tumble dry, soak, or wring.
- Do not fold tightly or press heavy items over the light edge.
- Do not iron or use hot airflow.

6 Air dry only



- Hang carefully or lay flat in a ventilated place until fully dry.
- Never use a dryer, iron, heater, or direct hot airflow.
- Let it dry fully before using or storing.



No machine wash



No dryer



Do not soak



No harsh solvents



No high heat

www.deskneko.com/care

Gentle care first. Use the product page or care label for item-specific instructions.