



DESKNEKO CARE

# Mahjong Mat Care Guide



Care for DeskNeko mahjong mats, tabletop mats, and soft game-night surfaces.



## Spot clean first

Soft cloth, cold to lukewarm water, mild soap only if needed.



## Hand wash when needed

Use gentle pressure. Do not twist, wring, or scrub hard.



## Machine wash only if needed

Never use bleach or a dryer. Air dry fully before use.

## 1 After receiving



- A light freshly printed smell can be normal and should fade after airing out.
- Lay flat to help curl or creases relax.
- Contact us if you notice a defect.

## 2 Daily play care



- Remove tiles and accessories before cleaning.
- Wipe dust and fingerprints with a soft cloth.
- Blot spills quickly and keep away from inks, dyes, and sharp objects.

## 3 Spot clean RECOMMENDED



- Use cold to lukewarm water with a soft cloth or sponge.
- Use a small amount of mild soap only when needed.
- Clean gently and avoid soaking stitched edges.

## 4 Hand wash WHEN NEEDED



- Use low-temperature water and mild soap.
- Do not twist, wring, or scrub aggressively.
- Rinse gently and press excess water out with a towel.

## 5 Machine wash ONLY IF NECESSARY



- Use a mesh bag or pillowcase to reduce friction.
- Choose low temperature, delicate settings, and mild soap.
- Do not use bleach or wash with rough/heavy items.
- Remove promptly and reshape gently.

## 6 Wrinkle care



- Use low heat from a hair dryer and smooth gently.
- Wipe lightly with a damp cloth, then air dry.
- Use warm cup pressing or a flat weight over a towel for creases.
- Avoid high heat, sharp folds, and long soaking.



Avoid bleach



No dryer



No harsh solvents



No hard scrubbing



Avoid long soaking

[www.deskneko.com/care](http://www.deskneko.com/care)

Gentle care first. Use the product page or care label for item-specific instructions.